

# Suggested Spreader Settings



The Spreader Settings below are recommendations only. The settings are approximate and will vary with ground speed pattern, adjustment and changes in the manufacturing of equipment. You should ALWAYS calibrate your spreader before applying product.

	<b>SPREADER TYPE</b>	<b>PER 1,000 SQ FT</b>				
		<b>1 lb.</b>	<b>2 lb.</b>	<b>3 lb.</b>	<b>4 lb.</b>	<b>5 lb.</b>
<b>SGN 90 GREENS GRADE</b>	ProScape-Prizelawn Bigfoot. bf1/ss	E	F	G	H	J
	PennMulch-Prizelawn HVO	E	F	G	H	J
	Cyclone	-	2	2 1/2	3	4
	Earthway Rotary	8	10	11	12	14
	Gandy	18	20	21	22	24
	Jet-Spread II	1 1/2	2	3	3 1/2	4
	Jet-Spread III	2	2 1/2	3	4	4 1/2
	Lely HR, 1250, 1500, 2010	-	2II	2 1/2 II	3 II	4 II
	Lely W	-	2II	2 1/2 II	3 II	4 II
	Lesco (letters)	C	D	E	G	H
	Lesco (numbers)	9	14	15	16	17
	Prizelawn CBR III	E	F	G	H	J
	Prizelawn CBR II	-	1 1/2	2	2 1/2	4
	Prizelawn LF-1	-	1	1 1/2	2	2 1/2
	Prizelawn MPR 1	-	1	2	4	5
	Scotts RX7	B	C	F	E	E
	Anderson Accupro SR-2000	E	G	H	J	J
	Anderson 2000	E	G	H	J	J
	Scotts R8A/SR1	E	G	H	J	K
	Scotts AP	E	G	H	J	J
Spyker	-	-	1 1/2	2	3 1/2	
Vicon	14	15	16	18	22	

	<b>SPREADER TYPE</b>	PER 1,000 SQ FT				
		1 lb.	2 lb.	3 lb.	4 lb.	5 lb.
<b>SGN 150 FAIRWAY GRADE</b>	ProScape-Prizelawn Bigfoot. bf1/ss	D	E	J	K	L
	PennMulch-Prizelawn HVO	D	E	J	K	L
	Cyclone	2	3	4	4 1/4	4 1/2
	Earthway Rotary	11	12	14	15	15
	Gandy	21	22	24	25	26
	Jet-Spread II	3	3 1/4	4	4 1/4	4 1/2
	Jet-Spread III	3	4	4 1/2	5	5
	Lely HR, 1250, 1500, 2010	2 II	3 II	4 II	5II	5 II
	Lely W	2 II	3 II	4 II	5 II	5 II
	Lesco (letters)	C	D	H	I	I
	Lesco (numbers)	8	10	15	16	17
	Prizelawn CBR III	D	E	J	K	L
	Prizelawn CBR II	2	2 1/2	4	4	4 1/2
	Prizelawn LF-1	1 1/2	2	2 1/2	3	3 1/2
	Prizelawn MPR 1	1 1/2	2	3	3	3 1/2
	Scotts RX7	C	D	E	F	G
	Anderson Accupro SR-2000	H	I	K	L	L
	Anderson 2000	H	I	K	L	L
	Scotts R8A/SR1	H	I	J	K	L
	Scotts AP	H	I	J	K	L
Spyker	2	3	3 1/2	4 1/4	4 1/2	
Vicon	18	20	22	23	24	

	<b>SPREADER TYPE</b>	PER 1,000 SQ FT				
		1 lb.	2 lb.	3 lb.	4 lb.	5 lb.
<b>SGN 220 STANDARD GRADE</b>	ProScape-Prizelawn Bigfoot. bf1/ss	E	J	L	N	O
	PennMulch-Prizelawn HVO	E	J	L	N	L
	Cyclone	3 1/2	4	4 1/2	5	5 1/2
	Earthway Rotary	12	14	15	16	18
	Gandy	22	22	28	28	30
	Jet-Spread II	3 1/2	4	4 1/4	5	5 1/2
	Jet-Spread III	4	4 1/2	5	5 1/2	6
	Lely HR, 1250, 1500, 2010	3 II	4 II	5 II	6 II	6 1/2 II
	Lely W	3 II	4 II	5 II	6 II	6 1/2 II
	Lesco (letters)	D	G	I	J	K
	Lesco (numbers)	10	15	17	21	22
	Prizelawn CBR III	E	J	L	N	O
	Prizelawn CBR II	2 1/2	4	4 1/2	5 1/2	6
	Prizelawn LF-1	2	2 1/2	3 1/2	4	4 1/2
	Prizelawn MPR 1	2	2 1/2	3 1/2	4	4 1/2
	Scotts RX7	D	E	G	I	J
	Anderson Accupro SR-2000	I	K	L	M	N
	Anderson 2000	I	K	L	M	N
	Scotts R8A/SR1	I	K	L	M	N
	Scotts AP	I	K	L	M	N
Spyker	3	4	4 1/2	4 3/4	5 1/4	
Vicon	20	22	24	26	30	